

# PAVE-SAFE™

Asphalt Emulsifier

## Application Tip Sheet

PAVE-SAFE™ is a remarkably effective and environmentally responsible alternative to diesel fuel that literally melts away asphalt and road oil spills, splatters and oversprays.



### **Paving Equipment:**

Determine if you have a light or heavy build-up of asphalt or road oil deposits. Heavy is more than 1/4 inch of build-up of asphalt.

- **Light Build-Up:** Spray on a liberal amount of PAVE-SAFE™ and let it sit for approximately one (1) to five (5) minutes, then pressure wash or steam clean deposits away.
- **Heavy Build-Up:** Spray on a liberal amount of PAVE-SAFE™ and let it sit for approximately fifteen (15) to twenty (20) minutes, then pressure wash or steam clean deposits away.

### **Prevent Sticking:**

PAVE-SAFE™ does a great job of preventing asphalt from sticking to the inside walls of your paver hoppers and truck beds.

### **Hand Tools:**

Use the Paving Equipment process described above to clean your hand tools.

Remember to always coat your hand tools with PAVE-SAFE™ before you start working with them. This will prevent asphalt build-up.

When a slight asphalt build-up starts to occur, recoat your hand tools with PAVE-SAFE™, then continue your shoveling or raking.

### **Application Note:**

PAVE-SAFE™ is safe on most painted surfaces, however always test PAVE-SAFE™ in an inconspicuous spot, prior to usage, for evidence of safety on finish. DO NOT spray PAVE-SAFE™ onto plexiglas or plastic parking light lenses as it will dull the finish.



**RHOMAR**