



# BRIDGE-CON™

Concrete or Metal Encapsulant

**DESCRIPTION:** BRIDGE-CON™ is specifically designed for encapsulating concrete or metal substructure components that have been exposed to corrosive chlorides. BRIDGE-CON™ is also excellent for protecting metal, wood and concrete components of bridges or salt storage domes.

**SURFACE PREPARATION - CONCRETE:** Always apply to a clean, dry surface, free of loose dirt and debris. Rhomar recommends cleaning surfaces that have been exposed to deicing chlorides with NEUTRO-WASH™ Chloride Neutralizer prior to application of BRIDGE-CON™.

**SURFACE PREPARATION - Metal:** Rhomar suggests applying BLACK-MAX Cathodic Rust Arrestor, as a primer to rusty metal components prior to application of BRIDGE-CON™.

**METHOD OF APPLICATION:** Rhomar recommends applying BRIDGE-CON™ with the BRIDGE-CON PISTOL-GRIP Spray Gun or by rolling with a thick nap roller. Apply product above 50°F.

**CLEAN UP OF BRIDGE-CON™:** When BRIDGE-CON™ is wet, you may clean tools and overspray with soap and water. When cured, remove with toluene or by sandblasting or with grinding wheel.

**COVERAGE OF BRIDGE-CON™:** Approximately 25-100 sq ft per gallon depending on porosity of substrate. Apply BRIDGE-CON™ to wet film thickness (WFT) of 15-20 mils.

- **PROTECTS** - Concrete or metal bridge components from corrosive chlorides!
- **FLEXIBLE** - Will not chip or crack with bridge movement!
- **ENVIRONMENTALLY SAFE** - Contains no harmful petroleum solvents!
- **UV & ALGAE RESISTANT** - Will not fade and contains mildewstat!
- **COLOR COORDINATED** - Blends with existing concrete!

Sold Exclusively By:  
**RHOMAR Industries Inc**  
2107 E Rockhurst St  
Springfield MO 65802 USA

NET CONTENTS: 1 US Quart/.946 Liters



**WARNING**

**HAZARDS IDENTIFICATION:**

May be harmful if swallowed or inhaled. May cause mild skin or eye irritation.

**PREVENTION:**

Wash thoroughly after handling. Avoid prolonged or repeated skin contact and avoid breathing vapors.

**RESPONSE:**

**SKIN:** Immediately take off all contaminated clothing and wash it before reuse. Wash skin with plenty of soap and water. If skin irritation or a rash occurs, get medical attention.

**EYES:** Rinse cautiously with water for several minutes. Remove contact lenses and continue rinsing. If eye irritation persists, get medical attention.

**INGESTION:** Rinse mouth. Do not induce vomiting. Get medical attention if you feel unwell.

**INHALATION:** Remove person to fresh air and keep comfortable for breathing. Get medical attention if you feel unwell.

**STORAGE:** Store in a cool, dry area at temperatures between 60°-110°F. Never allow product to freeze. Keep containers tightly sealed after usage, to prevent product from curing in container.

**DISPOSAL:** Dispose of contents/container in accordance with local, regional, national and international regulations.

**TO REORDER**

VISA, MASTER CARD, AND AMERICAN EXPRESS ACCEPTED

**1-800-688-6221**

solutions@rhomar.com • www.rhomar.com